

Manual, Assembly instruction: Brodit 834452

Console mount, Left NOT for use with horizontal devices.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the console edge and the center panel surrounding the gear shift, to widen the gap. Slide the gap opener, while in the gap, towards you approx. 3 inches/ 8 cm. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip.

2. Press the angled edge on the right side of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the thick end of the gap opener up behind the console sidewall by the carpet to create some distance between the sidewall and the carpet. (See arrow in picture) Press down on the top left side of the ProClip so the angled edge flexes down and hooks around the sidewall edge. Pull out the gap opener.

4. The ProClip is in place.