

Manual, Assembly instruction: Brodit 834461

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the left part of the ProClip into the gap between the panel surrounding the gear shift and the edge of the console.
2. Press down on the right side of the ProClip so the angled edge hooks under the edge of the console.
3. Press the right part of the ProClip toward the console so the angled edge hooks properly into place.
4. The ProClip is in place.