

Manual, Assembly instruction: Brodit 834522

Console mount, Left

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the right side of the ProClip over the edge of the console.
2. Press the left side of the ProClip downward so the angled edge hooks under the console.
3. Press the lower left side toward the console so the angled edge hooks into place properly.
4. The ProClip is in place.