

Manual, Assembly instruction: Brodit 834550

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the console edge and the console sidewall, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip.

2. Press/hook the angled edge on the right side of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Place your fingers underneath the upper part of the ProClip and pull so it flexes upwards, and hook the angled edge over the console edge. Then press down on top of the ProClip for best possible attachment of the adhesive tape.

4. The ProClip is in place.