

Manual, Assembly instruction: Brodit 834596

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the gear shift and the console frame, to widen the gap. Peel off the adhesive tape cover on the ProClip.

2. Press the angled edge on the left part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the console frame and the console sidewall. Press downward on the right side of the ProClip so the angled edge hooks into the gap next to the gap opener. Press the right part of the ProClip toward the console sidewall so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.