

Manual, Assembly instruction: Brodit 834703

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the console edge, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the left side of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Push firmly on the right side of the ProClip so it flexes downward and hooks around the console sidewall edge. Press forward on the lower side of the ProClip to make sure the angled edge is hooked all way around the console edge.

3. This ProClip fits on the right and left side of the center floor console. You can also use one on each side.

4. The ProClip is in place.