

Manual, Assembly instruction: Brodit 834710

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. The gap/seam underneath the center console is very tight so you will have to move the gap opener along the gap in a step by step manner (inserting one next to the other), to widen the gap. Press the thin end of one of the enclosed gap openers into the gap underneath the center console. Press the second gap opener into the gap next to the first gap opener. Pull out the first gap opener and insert it into the gap next to the second gap opener, and continue doing this until you have one gap opener in the mid area of the console.

2. Press the third gap opener into the gap on top of the center console. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener.

3. Support the placement of the upper part of the ProClip with your thumb and at the same time press on the lower part of the ProClip with your fingers so the angled edge hooks into the gap between the gap openers. Press until you see or hear/feel it click into place. Pull out all gap openers.

4. The ProClip is in place.