

Manual, Assembly instruction: Brodit 834751

Console mount ONLY for automatic gear shift.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the gear shift and the console, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the angled edge on the left side of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press down on the top right side of the ProClip so it flexes downward and the angled edge hooks around the panel edge in the console sidewall. Press until you hear/feel it snaps into place.
4. The ProClip is in place.