

Manual, Assembly instruction: Brodit 834771

Console mount ONLY for models with power outlet between seat heat buttons. NOT for models with speaker on side of console.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Place the left side of the ProClip over the console edge.

2. Press firmly on the right side of the ProClip so it flexes down towards the floor. Press until the angled edge on the lower part for the ProClip hooks around the console sidewall edge. Use your finger to press the mount towards the console sidewall to make sure the angled edge is hooked all the way around the console edge

3. The ProClip is in place.

4. The ProClip is in place.