

Manual, Assembly instruction: Brodit 834824

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press/Hook the angled edge on the lower part of the ProClip under the console edge.
2. Press the ProClip leftward and hook the angled edge over the edge of the console.
3. The ProClip is in place.
4. The ProClip is in place.