

Manual, Assembly instruction: Brodit 834848

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the angled edge on the left side of the ProClip over the console edge.
2. Press down on the top right side of the ProClip so it flexes downward and hooks around the console edge by the carpet.
3. The ProClip is in place.
4. The ProClip is in place.