

Manual, Assembly instruction: Brodit 834878

Console mount

1.)



2.)



3.)



4.)



Please read all the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the left side of the ProClip over the console edge.

2. Press downward firmly on the right side of the ProClip so it flexes down towards the floor. Press until the angled edge on the lower part of the ProClip hooks around the console sidewall edge.

3. The ProClip is in place.

4. The ProClip is in place.