

Manual, Assembly instruction: Brodit 834924

Console mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel of the adhesive tape cover on the ProClip. Place the angled edge on the left side of the ProClip over the console edge.
2. Press down firmly on the right side of the ProClip so the angled edge flexes downward and hooks around the lower console sidewall edge.
3. Press firmly on the side of the ProClip towards the seam in the console sidewall to make sure the angled edge goes all the way into the gap.
4. The ProClip is place.