

Manual, Assembly instruction: Brodit 835120

Console mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the console edge and the center console panel frame, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip.
2. From straight above, insert the angled left edge of the ProClip into the gap next to the gap opener.
3. Press the right side of the ProClip downward so the angled right edge hooks around the center console edge. Remove the gap opener.
4. The ProClip is in place.