

Manual, Assembly instruction: Brodit 835174

Console mount



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed gap opener into the gap between the center console top frame and the leather padding, to widen the gap. Remove the adhesive tape cover on the ProClip.

2. Insert the lower left edge of the ProClip into the gap on the right side of the frame surrounding the gear shifter and the center console wall. Move the ProClip downward/rightward until the angled right edge of the ProClip rests on top of the center console sidewall top.

3. Press the ProClip rightward and hook the angled right edge of the ProClip around the center console top frame, next to the gap opener. Remove the gap opener. Press down on the lower left side of the ProClip, making sure the adhesive tape fastens properly.

4. The ProClip is in place.