

Manual, Assembly instruction: Brodit 835224

Console mount ONLY for automatic transmission.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip will attach. Remove the adhesive tape cover on the ProClip. Hook the upper left edge of the ProClip over the left edge of the top of the right console side panel.

2. Flip/Press the ProClip downward so the angled lower edge hooks under the lower edge of the right side of the console side panel.

3. The ProClip is in place.

4. The ProClip is in place.