

Manual, Assembly instruction: Brodit 835226

Console mount NOT For models with a leather trim.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip will attach. Remove the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap in the console sidewall.
2. Hook the upper left edge of the ProClip over the left edge of the top of the right console side panel.
3. The ProClip is in place.
4. The ProClip is in place.