

Manual, Assembly instruction: Brodit 835227

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the seam in the console sidewall between the upper and lower sidewall panels.

2. Flip/Press the ProClip upward so the angled lower edge hooks behind the lower section of the console sidewall. Hook the upper left edge of the ProClip over the left edge of the top of the right console side panel.

3. The ProClip is in place.

4. The ProClip is in place.