

Manual, Assembly instruction: Brodit 835248

Console mount, High. NOT for T6, T8.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Place the angled left edge of the ProClip around the edge of the center console panel.
2. Push the right edge of the ProClip downward so the angled right edge hooks around the center console sidewall.
3. The ProClip is in place.
4. The ProClip is in place.