

Manual, Assembly instruction: Brodit 835314

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the left part of the ProClip into the gap between the center console and the console side wall.

2. Press down on the right side of the ProClip and hook the lower right edge of the ProClip under the console side wall.

3. The ProClip is in place.

4. The ProClip is in place.