

Manual, Assembly instruction: Brodit 835343

Console mount NOT for S60 T6, T8, V60 T6,T8.



Please read all of the instructions and look at the pictures before attaching the ProClip

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the angled edge on the left part of the ProClip over the console edge.

2. Press downward on the right side of the ProClip so the angled edge on the right part of the ProClip hooks under the console sidewall.

3. Press downward on the ProClip so the adhesive tape attaches.

4. The ProClip is in place.