

Manual, Assembly instruction: Brodit 835354

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the lower edge of the ProClip into the gap between the center console and the floor carpet panel.

2. Rotate the ProClip upward. At the same time, press in on the bottom of the ProClip so the lower edge of the ProClip hooks under the floor carpet panel.

3. Pull the left part of the ProClip upwards and hook the left edge over the top of the center console, onto the cup holder opening.

4. The ProClip is in place.