

## Manual, Assembly instruction: Brodit 835360

Console mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Press the left part of the ProClip into the gap between the center floor console panel and the sidewall.
2. Press downward on the right side of the ProClip and hook the lower right edge under the sidewall of the center floor console
3. If the ProClip feels too loose, attach the ProClip further to the front of the console, closer to the dashboard. The ProClip has anti gliding rubber pads on the attaching edges to keep the mount from sliding back.
4. The ProClip is in place.