

Manual, Assembly instruction: Brodit 835381

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the left edge of the ProClip over the top side of the center console.
2. Press down on the right side of the ProClip so the lower right edge of the ProClip hooks under the center console side wall.
3. The ProClip is in place
4. The ProClip is in place.