

Manual, Assembly instruction: Brodit 835399

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap in the center console sidewall, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press the thin lower edge of the ProClip into the gap next to the gap opener.
3. Press the left part of the ProClip leftward/downward. Hook the notched left edge of the ProClip under the frame surrounding the display. Pull out the gap opener.
4. The ProClip is in place.