

Manual, Assembly instruction: Brodit 835438

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Hook the lower edge on the right part of the ProClip under the console sidewall.
2. Lift the left edge of the ProClip over the top of the console edge. Hook/Press the upper edge of the ProClip into the gap between the padded console and the console trim.
3. The ProClip is in place.
4. The ProClip is in place.