

Manual, Assembly instruction: Brodit 835466

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the floor console sidewall, to widen the gap.
2. Press the lower edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press the ProClip upwards/leftwards and hook the upper edge over the silver trim. Press until you hear/feel it snaps into place in the gap.
4. The ProClip is in place.