

Manual, Assembly instruction: Brodit 835471

Console mount, Left

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the right edge of the ProClip over the center floor console edge.

2. Press downwards on the left side of the ProClip. At the same time, press the left part of the ProClip toward the sidewall and hook the lower edge of the ProClip under the floor console.

3. The ProClip is in place.

4. The ProClip is in place.