

Manual, Assembly instruction: Brodit 835496

Console mount ONLY for automatic gear shift.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the angled edge on the upper part of the ProClip over the center console frame.
2. Press downward on the left side of the ProClip and hook the angled lower edge under the center console frame.
3. This ProClip can also be placed on the right side of the center console.
4. The ProClip is in place.