

Manual, Assembly instruction: Brodit 835510

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console edge and the panel surrounding the gear shift, to widen the gap (the lower inside gap). Peel off the adhesive tape cover on the ProClip.
2. Align the front edge of the ProClip with the front edge of the frame surrounding the gear shift. Press the left edge of the ProClip all the way into the gap next to the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap in the center console side wall. Press down on the right side of the ProClip and hook the lower edge into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.