

Manual, Assembly instruction: Brodit 835515

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the lower part of the ProClip into the gap between the center console and the sidewall.
2. Press the lower edge of the ProClip into the gap, at the same time press/flip the upper part of the ProClip upward so the curved lower edge hooks behind the center console sidewall.
3. Hook the upper edge of the ProClip, with adhesive tape, over the center console panel. Press down on top of the ProClip so the adhesive tape attaches properly.
4. The ProClip is in place.