

Manual, Assembly instruction: Brodit 835561

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place. This mount consists of two parts: A mount and a faceplate.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover on the mount. Hook the upper edge of the mount over the console frame so the front edge of the mount is aligned just forward of the screen frame.

2. Press the thin end of the enclosed gap openers into the gap on the side of the console, one on each side of the mount. Press down on the top of the mount so the lower edge clips/hooks into the gap between the gap openers. Press on the side of the lower edge of the mount to ensure it is properly in place. Pull out the gap openers.

3. Place the locking washer into the recess on top of the riser block. Place the faceplate over the riser and angle as desired. Secure the faceplate to the mount using the included machine screw.

4. The ProClip mount is in place.