

Manual, Assembly instruction: Brodit 835564

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the upper part of the ProClip over the center console frame.
2. Press down on the right side of the ProClip and hook the lower edge under the center console side wall.
3. Press on the lower part of the ProClip so the angled edge hooks into place properly.
4. The ProClip is in place.