

Manual, Assembly instruction: Brodit 835607

Console mount, Left

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. 1 Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console side wall and top, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the right part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press downward on the left side of the ProClip and hook the angled edge into the gap in the center console side wall.

4. The ProClip is in place.