

Manual, Assembly instruction: Brodit 835642

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap in the floor console side wall, to widen the gap. Peel off the adhesive tape cover on the ProClip.

2. Place the left part of the ProClip over the floor console frame.

3. Press down on the right side of the ProClip so the J-shaped edge hooks into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.