

Manual, Assembly instruction: Brodit 835652

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the thin end of the enclosed gap opener into the gap between the center console and the side wall, to widen the gap.
2. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener.
3. Press down on the left side of the ProClip and hook the angled edge under the console side wall. Pull out the gap opener.
4. The ProClip is in place.