

## Manual, Assembly instruction: Brodit 835656

Console mount



**Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.**

1. Hook the upper edge of the ProClip over the floor console.
2. Press downward on the ProClip so the lower edge hooks/snaps into place under the floor console inner sidewall.
3. The ProClip is in place.
4. The ProClip is in place.