

Manual, Assembly instruction: Brodit 835678

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place. This mount consists of two parts: a faceplate and a mount.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the upper edge of the mount over the side of the console.

2. Press the thin end of the enclosed gap opener into the gap under the console sidewall, to widen the gap. Press downward on top of the mount, and press the lower part toward the console sidewall so the edge hooks into the gap next to the gap opener. Pull out the gap opener.

3. Place the included locking washer into the recess on top of the mount. Place the faceplate onto the mount. Adjust the faceplate into the desired angle. The faceplate may be installed for use by the driver or the passenger. Attach the faceplate to the mount with the included screw.

4. The ProClip mount is in place. The mount may be installed on the drivers or passengers side of the console.