

Manual, Assembly instruction: Brodit 835739

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place. It is important to place the ProClip in the exact same position as shown in the pictures.

1. Hook the upper left part of the ProClip over the edge of the floor console.
2. Press downwards on the right side of the ProClip and hook the lower right edge into the gap in the floor console sidewall.
3. Press the lower edge of the ProClip toward the sidewall so the edge hooks properly in place in the gap.
4. The ProClip is in place.