

Manual, Assembly instruction: Brodit 835759

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the thin end of the enclosed gap opener into the gap between the floor console top panel and side console, to widen the gap. The gap opener should be placed in front of the coin tray. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover. Press the upper part of the ProClip into the gap next to the gap opener. Make sure it sits flush with the top of the console. Pull out the gap opener.

2. Press down on top of the ProClip so the lower edge is in line with the bottom of the console side wall. Press the lower edge into the gap between the floor console and the carpet.

3. View from the side.

4. The ProClip is in place.