

Manual, Assembly instruction: Brodit 835778

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached after the mount is in place.

1. Press the lower angled edge into the gap in the center console side wall.
2. Pull the mount upwards and hook the angled upper edge over the center console frame.
3. View from the side.
4. The ProClip is in place.