

Manual, Assembly instruction: Brodit 835788

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached after the mount is in place.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the center console and the frame surrounding the gear shift, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover.

2. Press the lower edge of the mount into the gap between in the center console side wall.

3. Pull the mount upward and hook the upper edge into the gap next to the gap opener. Press down on the mount so it attaches properly. Pull out the gap opener.

4. The ProClip is in place.