

Manual, Assembly instruction: Brodit 835792

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover. Place the upper edge of the mount over the center console frame.

2. Press down on the mount so the angled lower edge hooks into the gap in the center console side wall. Press the mount toward the center console so the angled edge goes all the way into the gap.

3. View from the side.

4. The ProClip is in place.