

Manual, Assembly instruction: Brodit 835797

Angled mount

1.)



2.)



3.)



4.)



1. Gently clean the area where the mount will attach. Remove the adhesive tape cover. The location of where to install this mount is to the left of the center shifter buttons near the start button. Gently press the bottom lip into the seam shown in the picture above. You will feel it slide into the seam with minimal effort.

2. Insert the supplied gap opener into the seam between the soft material - the hard plastic, right above where the mount will attach. (See the picture above) Gently pull the mount toward you, flexing the mount between the soft material and hard plastic. It will hook in the open seam. (See the picture above)

3. Apply gentle downward pressure to make contact with the adhesive and the soft material. Remove the gap opener.

4. The proclip is in place.