

Manual, Assembly instruction: Brodit 835849

Console mount NOT for T6, T8.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the angled edge on the left part of the ProClip over the center console edge.

2. Press downward on the right side of the ProClip so the angled right edge hooks under the center console sidewall. Press the right side of the ProClip toward the center console so the angled edge hooks into place properly.

3. The ProClip is in place.

3. The ProClip is in place.