

Manual, Assembly instruction: Brodit 835860

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to gently clean the area where the mount will be installed. Remove the backing from the adhesive tape. Insert the included gap opener into the seam along the right side of the console forward of the bend.

2. Insert the lower lip of the mount into the seam.

3. Pulling back on the mount face and pushing in on the middle of the mount, flex the top of the mount over the console trim until the left edge of the mount is pressed against the transmission control housing.

4. The ProClip is in place.