

Manual, Assembly instruction: Brodit 835865

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the angled edge on the left part of the ProClip over the center console edge.
2. Insert the gap opening between the hard plastic trim and the soft trim on the lower part of the center console.
3. Press downward on the right side of the ProClip so the angled right edge hooks under the center console sidewall.
4. The ProClip is in place.