

Manual, Assembly instruction: Brodit 835880

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover. Hook the left part of the mount over the center console frame.
2. Press the thin end of the enclosed Gap Opener (Spaltöffner)s into the gap underneath the center console frame, to widen the gap.
3. Press down on the right side of the mount so the angled lower edge hooks into the gap between the Gap Opener (Spaltöffner). Press the right side of the mount upward toward the center console frame, so the angled edge goes all the way into the gap. Pull out the Gap Opener (Spaltöffner)s.
4. The ProClip is in place.