

Manual, Assembly instruction: Brodit 835901

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. This ProClip will be installed on the passenger side of the center console. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the lower lip of the ProClip into the gap between the soft material and the hard plastic underside of the console.

2. Pull the upper part of the ProClip up and over the top of the center console.

3. The ProClip is in place.

4. The ProClip is in place.