

Manual, Assembly instruction: Brodit 836036

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower edge of the mount under the center console sidewall.
2. Pull the upper part of the mount upward and hook the left edge over the center console frame.
3. Press downward on the upper edge so it hooks into place properly and the adhesive tape attaches.
4. The ProClip mount is in place.